

Luminex Plate Layout for aliquoting samples onto 96-well plate

	1	2	3	4	5	6	7	8	9	10	11	12
A					Sample 7		Sample 15		Sample 23		Sample 31	
B					Sample 8		Sample 16		Sample 24		Sample 32	
C			Sample 1		Sample 9		Sample 17		Sample 25		Sample 33	
D			Sample 2		Sample 10		Sample 18		Sample 26		Sample 34	
E			Sample 3		Sample 11		Sample 19		Sample 27		Sample 35	
F			Sample 4		Sample 12		Sample 20		Sample 28		Sample 36	
G			Sample 5		Sample 13		Sample 21		Sample 29		Sample 37	
H			Sample 6		Sample 14		Sample 22		Sample 30		Sample 38	

Sue Venable
 Manager, Core C
 svenable@bcm.edu
 832-824-8253

Note:

- please use a **Costar 3363** or other brand v-bottom polypropylene 96-well plate to aliquot your samples.
- use a Silverseal plate sealer (**Bioexpress, Cat# T3025-8B**) to seal the plate
- deliver the plate on dry ice to the Feigin Center, Room 830.12